


POLARIS GENERAL 2 SEAT AUDIO ROOF & LED LIGHT SYSTEM

P/N: TF030304



THUMPER FAB

Aluminum Audio Roofs ♦ Bumpers & Roll Cages ♦ UTV Accessories

Thumper Fab

5103 Elysian Fields Rd, Marshall, Tx 75672

Customer Service: 903-472-0928

www.thumperfab.com

POLARIS GENERAL 2 SEAT AUDIO ROOF & LED LIGHT SYSTEM



P/N: TF030304

PARTS

REF	QTY	PART DESCRIPTION
1	3	5/16" Flat Washers
2	3	5/16" Nuts
3	5	5/16" Bonded Washer
4	2	5/16" x 1 1/2" Button Head Cap Screws
5	3	5/16" x 3/4" Button Head Cap Screw
6	1	Power Cable (attached to roof)

TOOLS


- 3/16", 5/32" and 9/64" Allen Wrenches
- 1/2" Wrenches or Sockets

BEFORE YOU BEGIN

If you do not feel comfortable installing your **Thumper Fab** Audio Roof and LED Light System please see your nearest Polaris® Dealer for installation.

INSTALLATION INSTRUCTIONS

1. Remove stock roof.
2. Install **FOAM MOUNTING TAPE** from hardware kit on sides of frame. You will want to butt the foam up against the edge of the existing foam on front of roof.
3. With at least one person assisting you, lift the **AUDIO ROOF** into place over your General and slowly set it onto vehicle.
4. Align holes on front of **AUDIO ROOF** with stock holes on vehicle frame. Run 1 1/2" button head cap screw and bonded washer at an angle through holes on top of roof into u-spring nut as pictured using a 3/16" allen wrench.



6. Insert 3/4" button head cap screw and flat washer from bottom of bracket through roof, then secure with bonded washer and nut. Use a 1/2" wrench for nut and 3/16" allen wrench for screw.



7. You may now **TIGHTEN ALL HARDWARE**.

**TORQUE STANDOFF
HARDWARE TO 10 FT-LBS**


5. Hook rear mount brackets on the back bar of roll cage and position them in line with holes on rear of roof.

WIRING INSTRUCTIONS

1. Remove rear seat on driver's side and run power cable along the vehicle's frame as shown. Use zipties to secure cable to frame.




2. Run cable through hole into battery compartment. Connect black wire to negative battery terminal. Connect white wire to inline breaker, then run red wire from breaker to positive battery terminal.



CONNECTION INSTRUCTIONS

1. Turn on power to Control Unit (front, center of underside of roof).
2. Install mobile app to connect via Bluetooth® to 8-panel Control Switch using QR code, or visit <http://download.appglobalmarket.com/happylightingdownload.html>
3. To pair your device to the Rockford Fosgate® PMX-0 media receiver, you will need to press "SRC" button on unit until you hear "Bluetooth Mode".



SRC
BUTTON

FIG. 11

CONTROL UNIT
POWER SWITCH

4. Turn on lights & music and...

**LET THE
THUMPIN' BEGIN**



THUMPER **FAB**

Aluminum Audio Roofs ♦ Bumpers & Roll Cages ♦ UTV Accessories

Thumper Fab

5103 Elysian Fields Rd, Marshall, Tx 75672

Customer Service: 903-472-0928

www.thumperfab.com