# POLARIS RANGER 3-SEATER & CREW

## **AUDIO ROOF & LED LIGHT SYSTEM**

P/N: TF010301 - TF010309



#### **Thumper Fab**

5103 Elysian Fields Rd, Marshall, Tx 75672 Customer Service: 903-472-0928

www.thumperfab.com

## **POLARIS RANGER 3-SEAT & CREW**

#### **AUDIO ROOF & LED LIGHT SYSTEM**

P/N TF010301 - TF010309



#### **FEATURES**

- Rockford PMX-0 media receiver w/ Bluetooth®
- Rockford Prime 6"× 9" 3-way speakers (4)
- Rockford Prime R2 10" Subwoofer
- Rockford Punch PBR300X4 300 watt Amp
- Rockford Punch PBR300X1 300 watt Amp
- RGB LED Rock Lights w/ Bluetooth® (4)
- 40" Quad Row Front LED Light Bar (1)
- 3" Side/Rear LED Cube Lights (6)
- 2 Year Warranty

## **TOOLS REQUIRED**

- · Safety Glasses
- · 1/2" Socket & Ratchet
- 1/2" Combination Wrench
- · Allen Wrench (included)

#### **BEFORE YOU BEGIN**


If you do not feel comfortable installing your **Thumper Fab** audio roof, please see your nearest Polaris® Dealer for installation

#### **PARTS**

2 3 4 5 6	QTY  2 1 2 1 3  DED (	PART DESCRIPTION  Rear. Mounting. Assembly. (2.1-2.7.)  Vertical. Bar. Clamp. Kit. (3.1-3.5)  D-foam. Insulation  60. Amp. In-Line. Fuse. Box  Battery. Cables. (2. red., 1. black)	7 8 9 10	<b>QTY</b> 6 2 1	PART DESCRIPTION  Spare Fuses Panel Decals (extra)	
3 4 5 6 <b>NCLU</b>	1 2 1 3	Vertical Bar. Clamp. Kit (3, 1-3,5) D-foam. Insulation 60. Amp. In-Line. Fuse. Box Battery. Cables. (2. red,1. black)	8 9	2		
4 5 6 <b>NCLU</b>	2 1 3	D-foam Insulation 60 Amp In-Line Fuse Box Battery Cables (2 red, 1 black)	9		Panel Decals (extra)	
5 6 NCLU	1 3	D-foam Insulation 60 Amp In-Line Fuse Box Battery Cables (2 red, 1 black)	-	1		
6 NCLU	3	Battery Cables (2 red, 1 black)	10		Allen, Wrench. (in. Vertical Clamp. kit)	
NCLU	_			1	PMX-0. Media. Receiver, Manual	
	DED (		11	1	Ranger. Audio. Roof. Manual	
REF		ON AUDIO ROOF				
	QTY	PART DESCRIPTION	REF	QTY	PART DESCRIPTION	
1.1	3	5/16". x. Nut	1.5	2	5/16" Flat Washer	
1.2	3	5/16". Flat Washer	1.6	2	5/16". Nut	
1.3	2	Center, Mounting, Bracket	1.7	1	Power. Supply. Cord	
1.4	2	5/16". x. 1.5. Bolt				
REAR MOUNTING ASSEMBLY ——————				VERTICAL BAR CLAMP		
REF	QTY	PART DESCRIPTION	(KIT N	OT INCLU	IDED WITH 3-SEATER TOPS) PART DESCRIPTION	
2.1	4	5/16" x 1 Bolt				
2.2	2	5/16" Bonded Washer	3.1	2	Top Fastener	
2.3	4	5/16" Flat Washer	3.2	2	Bottom Fastener	
2.4	2	5/16" Lock Washer	3.3	4	Rubber Insert	
2.5	2	5/16" Nut	3.4	4	Lock Washer	
2.6	2	5/16" Spot Weld Nut	3.5	4	Hex Bolt	
2.7	2	Z-Bracket		a		
_		<b>2</b>		_		
<b>3</b>				32	3	
<b>3</b>				a	VERTICA BAR CLAI	
2		REAR MOUNTING ASSEMBLY		•	FIG. 3	

### INSTALLATION INSTRUCTIONS


 Install D-foam Insulation on sides of roof.
 Make sure foam sits between audio roof and ROPS\*. Trim excess if needed. (FIG. 4)




 Remove the three sets of nuts and washers from LH, RH, and Center bolts on front of roof and retain for use in STEP 6. Leave Standoff and O-ring in place. (FIG. 5)




- Remove bolts, washers, and nuts from both rear mount Z-Brackets included in Hardware Kit. (FIG. 2)
- 4. Install lower, non-slotted side of Z-Bracket to ROPS\*. Repeat on opposite side. (**FIG. 6**)



 Lay Audio Roof on top of ROPS\*. Align rear mounting holes on Audio Roof with upper, slotted side of Z-bracket and loosely Install using the bolts, washers, and nuts from Step 4. (FIG. 7)



 Install front of roof to ROPS\* using retained nuts and washers from step 2. Make sure Standoffs and O-rings sit between the audioa roof and the ROPS. (FIG. 8)




 You may now fully tighten the three front nuts and and two rear spot weld nuts to the ROPS\* using a 1/2" socket and wrench.


# TORQUE STANDOFF HARDWARE TO 10 FT-LBS

3-seat models TF010306 ,TF010308 & TF010309 should skip to step 9.]

8. Install Vertical Bar Clamp (**FIG.3**), included in Hardware Kit, to Center Mounting Bracket (on Audio Roof) and ROPS\* using rubber inserts. (**FIG. 9**)



- 9. Lift rear seat and disconnect black negative (-) and red positive (+) cable from battery.
- Run Power Supply Cord from Audio Roof to the In-Line Fuse, then run Battery Cables from Hardware Kit to battery terminal. (FIG. 10)




### **OPERATION**

- 1. Turn on power to Control Unit (front, center of underside of roof). (FIG. 11)
- 2. Install mobile app to connect via Bluetooth® to 8-panel Control Switch using QR code, or visit

#### http://download.appglobalmarket.com/happylightingdownload.html

3. To pair your device to the Rockford Fosgate® PMX-0 media receiver, you will need to press "SRC" button on unit until you hear "Bluetooth Mode". (FIG. 11)





4. Turn on lights & music and...





#### **Thumper Fab**

5103 Elysian Fields Rd, Marshall, Tx 75672 Customer Service: 903-472-0928

www.thumperfab.com