




Aluminum Audio Roofs - Bumpers & Roll Cages - UTV Accessories

Polaris Ranger Roof Installation



Thumper Fab

5103 Elysian Fields Rd, Marshall, Tx 75672

Customer Service: 903-472-0928

www.thumperfab.com

Ver. 0423

INSTALLATION

Required

- 9/64” Hex
- 1/2” Socket
- 10mm Socket or Pliers
- Torque Wrench

Hardware

Ref	Description	Quantity
A	Z-Bracket Assembly	2
A1	5/16” x 1” Hex Bolt	4
A2	5/16” Flat Washer	4
A3	5/16” Bonded Washer	2
A4	5/16” Split Lock Washer	2
A5	5/16” Spot Weld Nut	2
A6	5/16” Flange Nyloc Nut	2
A7	Z-Bracket	2
B	Vertical Bar Clamp Kit	1
B1	#8-32 x 3/4” Cap Screw	4
B2	#8 Split Lock Washer	4
B3	5/16” Flat Washer	4
B4	5/16” x 1” Hex Bolt	2
B5	5/16” Nyloc Nut	2
C	D-Foam	1
D	60A Breaker	1
E	5/16” x 1-1/2” Hex Bolt(on roof)	3
F	5/16” Bonded Washer(on roof)	3
G	5/16” Flat Washer(on roof)	3
H	5/16” Nut(on roof)	3
I	1/2” Spacer(on roof)	3

Battery Isolation System

A battery isolator system with separate batteries, one main-starter and one auxiliary battery, is required. The recommended isolator is ----.




Figure 1

Install D-Foam

Cut the D-foam **Ref C** in half, so that both pieces are equal length. Install the D-foam where shown in **Figure 2**. Cut off any loose material.




Figure 1

INSTALLATION

Remove the Nuts from Spacer Bolts

On the front of the roof, remove the 5/16" nyloc nuts **Ref H** and the 5/16" flat washers **Ref G** from the 5/16" x 1-1/2" bolts **Ref E**. Do not remove the 1/2" spacers **Ref I** which should stay on the roof.

Remove the Stock Roof (if applicable)

The stock polyroof is held on by push pins and shouldn't require any tools to remove. Remove the stock roof and set it aside.

Install the Z-Brackets

Position the Z-brackets **Ref A** on the ROPS(roll-over protection system, a.k.a. the roll cage) on the rear corner, as shown in **Figure 2**.




Figure 2

Install the Vertical Bar Clamp On Roof(if applicable)

Install the vertical bar clamp **Ref B** on the audio roof, as shown in **Figure 4**. Before continuing to the next step, use the 9/64" hex drive to remove the bottom half of the bar clamp to place over the ROPS.




Figure 4

Place Audio Roof on Unit

With the help of two people, place the audio roof on top of the ROPS and align the mounting holes between the audio roof and the ROPS. Make sure that the 5/16" x 1-1/2" bolts **Ref E** go through the holes on the ROPS.

INSTALLATION

Tighten Down the Roof to Spec

Use the torque wrench with the 1/2" socket to tighten down the rear hardware to **10FT-LBS**. *Overtightening may cause gaps where water can enter the roof and damage the electronics.*

Then install the other half of the bar clamp using the 9/64" hex drive. Finally, tighten the hardware **Ref H** at the front of the roof using the 1/2" socket, making sure to include the 5/16" flat washers **Ref G**.

Wiring the Audio Roof

Lift up the back seat to gain access to the electrical compartment. Connect wire to one side of the 60A breaker **Ref D**.

Connect the other side of the fuse to the wiring harness on the audio roof. Correct wiring is shown in **Figure 5**. ***Note: incorrectly connecting the wires may result in damage to the vehicle or audio roof.***




Figure 5

Test the Audio

Press the power button located on the control panel. Follow the manufactures instructions for audio and light operations.





For additional help with installation, checkout out our
YouTube channel or send us an email to
support@thumperfab.com

5103 Elysian Fields Rd, Marshall, Tx 75672
Customer Service: 903-472-0928

www.thumperfab.com

Ver. 0122