




# THUMPER FAB

Aluminum Audio Roofs ♦ Roll Cages ♦ UTV Accessories

## Can-Am Defender Cell Phone Charging Mount

SKU: TF040910



### Thumper Fab

5103 Elysian Fields Rd, Marshall, TX 75672

Customer Service: 903-472-0928

[www.thumperfab.com](http://www.thumperfab.com)

Ver. 0124

# Can-Am Defender Cell Phone Charging Mount

SKU: TF040910




## PARTS

REF	QTY	DESCRIPTION
1	1	Dash Mount Bracket
2	1	Wiring Harness
3	1	Phone Charging Unit
4	1	Ball Mount
5	1	Adjustable Swivel Mount
HARDWARE KIT		
A	5	#14 x 3/4" Truss Screws
B	4	#8-32 x 1/2 Socket Cap Screw
C	4	#8-32 Nylon Lock Nut
D	1	Cable Clamp

## TOOLS

- Drill
- 1/8" Drill Bit
- 1/2" Drill Bit
- Phillips Head Screwdriver
- 11/32" Wrench
- 10mm Socket
- Ratchet
- 9/64" Allen
- T30 Torx
- Marker




### BEFORE YOU BEGIN

If you do not feel comfortable installing your **Thumper Fab** Phone Charger, please see your nearest Can-Am® Dealer for installation.

# INSTALLATION INSTRUCTIONS

## Installation Preparation

Place the dash mount bracket (1) into position and use a marker to mark holes to be pre-drilled before installation (**FIG 1**).



**FIG 1 - Use Mount Bracket (1) as a template to mark holes**

Use an 1/8" drill bit and drill to drill pilot holes for mounting hardware (**FIG 2**).



**FIG 2 - Drill pilot holes with 1/8" Drill Bit**

# INSTALLATION INSTRUCTIONS

## Installation Preparation

Using a 1/2" drill bit, drill a hole in the location shown for wire routing (**FIG 3**).



**FIG 3 - Use 1/2" Drill Bit to make hole for wire routing**

Feed the terminal end of the wiring harness (**2**) through the hole drilled in step 3 (**FIG 4**).



**FIG 4 - Feed Terminal end of Wiring Harness (2) through hole**

# INSTALLATION INSTRUCTIONS


## Installation Preparation

Using a 9/64" allen and an 11/32" wrench. Fasten the ball mount (4) to mount bracket (1) using 4 x #8-32 x 1/2" socket cap screws (2) and 4 x #8-32 nylon lock nuts (C) (FIG 5).



**FIG 5 - Mount Ball Mount to Mount Bracket using 9/64" Allen and 11/32" Wrench**

Fasten the mount bracket (1) to the unit using 5 x #14 x 3/4 truss screws (A) and a phillips head screwdriver (FIG 6).



**FIG 6 - Mount Bracket to vehicle using a Phillips Head Screwdriver**



# INSTALLATION INSTRUCTIONS

## Installation

Use the adjustable swivel mount (5) to mount the phone charging unit (3) to the ball mount (4) (FIG 7).



**FIG 7 - Mount the Phone Charging Unit (3) to the Ball Mount (4) using the Adjustable Swivel Mount (5)**

Connect the pigtail on the phone charging unit (3) to the pigtail on the wire harness (2). Remove factory T30 Torx bolt and install cable clamp (D) to fasten wiring harness (2) to face of plastic (FIG 8).



**FIG 8 - Connect pigtail from Phone Charging Unit (3) to the Wire Harness (2)**

# INSTALLATION INSTRUCTIONS


## Installation

Pull back the switch panel in the center of the dash to gain access to the under-dash bus bar. Use a 10mm socket to remove OEM flange nuts (FIG 9).



**FIG 9 - Gain access to bus bar and remove OEM nuts in preparation for wiring**

Connect the terminals of the wiring harness (2) to the color matching posts on the bus bar and fasten using OEM flange nuts and a 10mm socket (FIG 10).



**FIG 10 - Connect Wiring Harness (2) to bus bar using 10mm Socket**

# INSTALLATION INSTRUCTIONS

## PRODUCT DISCLAIMER

The installation of products sold or manufactured by Thumper Fabrication, LLC (Thumper Fab) including, but not limited to suspension components such as lift kits, audio roofs, roll cages, frame stiffener kits, and tires that exceed the original specifications for the vehicle, may change the vehicle's center of gravity and handling characteristics both on- and off-road. You are aware that the installation of tires that are larger than original vehicle specifications may reduce the effectiveness of the braking system. Use of these products may place added stress to the original factory vehicle components which could cause them to weaken or possibly fail.

Products sold or manufactured by Thumper Fab are intended for off-road use only. Operation of a vehicle modified with these products on a road could result in serious bodily injury or death, and such operation may violate the laws of your state or municipality. You agree to operate your vehicle exclusively in the manner intended by the vehicle manufacturer. You agree that failure to safely and reasonably operate your vehicle could result in serious bodily injury or death, and that, as a result of installation of this product(s) to your vehicle, extreme care must be taken to prevent vehicle rollover or loss of control, which may be more likely to occur as a result of said modifications. You will avoid unsafe maneuvers, including sudden sharp turns or other abrupt maneuvers, which could make a vehicular accident more likely. You understand that Thumper Fab is not responsible or liable for any damages or any injuries to yourself or your passengers that could occur upon possible accidents due to driver error, incorrect installations, bad judgment, incompatibility with other aftermarket accessories or natural disasters to the fullest extent allowable by law. You will have all vehicle occupants fasten seatbelts, if equipped, and wear proper safety equipment, such as DOT approved helmet and eye protection prior to operating the vehicle. You understand and acknowledge that failure to wear proper safety equipment may increase the risk of serious bodily injury or death to yourself and any passengers.

Proper installation of products sold or manufactured by Thumper Fab requires knowledge of the factory recommended procedures for removal and installation of original equipment components. Installation of these products without proper knowledge and experience may affect the performance of these components and the safety of the vehicle and cause serious bodily injury or death. It is strongly recommended that a certified mechanic familiar with the installation of similar components perform the product(s) installation.

Prior to installing any products sold or manufactured by Thumper Fab, you will perform or cause to be performed an inspection of their vehicle to confirm its condition is suitable for the installation of these products. A proper inspection of the vehicle includes confirmation that the vehicle has not been in a collision and is free of corrosion. If the vehicle is suspected to have been in a collision or misused, or is otherwise unsuitable for modification, you will not install the product(s). You will continue to inspect the vehicle prior to each use to confirm its condition is suitable for its intended use, and you acknowledge that the failure to do so may result in serious bodily injury or death, as well as damage to the vehicle itself.

You will install any warning labels provided with the product so it may be prominently seen by yourself and all passengers. You will notify all passengers of the modifications performed to your vehicle prior to operation.

Insurance companies may handle coverage of a modified vehicle differently. Please check with your insurance carrier prior to modifying the vehicle to ensure your coverage remains sufficient. Installation of this product(s) may void your vehicle warranty. If this is a concern, please check with the manufacturer or dealer before purchase or installation of this product(s).





**THUMPER FAB**

**Thumper Fab**

5103 Elysian Fields Rd, Marshall, Tx 75672  
Customer Service: 903-472-0928

[www.thumperfab.com](http://www.thumperfab.com)