


**CF Moto Z10 - 2 Seat
Aluminum Roof**

SKU: TF330402



Thumper Fab
5103 Elysian Fields Rd, Marshall, TX 75672
Customer Service: 903-472-0928

CF Moto Z10 2-Seat Aluminum Roof

SKU: TF330402



PARTS

REF	QTY	DESCRIPTION
1	1	Aluminum Roof
2	1	Rear Wing - Driver
3	1	Rear Wing - Passenger
4	1	Light Bar Bracket - Driver (OPTIONAL)
5	1	Light Bar Bracket - Passenger (OPTIONAL)
6	1	Rear Light Bar Bracket (OPTIONAL)
7	170 in	Adhesive Foam
HARDWARE KIT		
A	8	M8x20mm Button Head Screw
B	6	M8 Fender Washer
C	6	M8 Nylon Lock Nut

TOOLS

- 4mm Allen Wrench
- 5mm Allen Wrench
- 13mm Socket and Wrench
- Snips
- Drill with assorted drill bits

BEFORE YOU BEGIN

If you do not feel comfortable installing your **Thumper Fab** Aluminum Roof, please see your nearest Thumper Fab® Dealer for installation.

Torque Specs:

SIZE (STANDARD)	GRADE 5	GRADE 8	SIZE (METRIC)	CLASS 8.8	CLASS 10.9
5/16"	15 ft/lbs	20 ft/lbs	6MM	5 ft/lbs	9 ft/lbs
3/8"	30 ft/lbs	35 ft/lbs	8MM	18 ft/lbs	23 ft/lbs
7/16"	45 ft/lbs	60 ft/lbs	10MM	32 ft/lbs	45 ft/lbs
1/2"	65 ft/lbs	90 ft/lbs	12MM	55 ft/lbs	75 ft/lbs
9/16"	95 ft/lbs	130 ft/lbs	14MM	85 ft/lbs	120 ft/lbs
5/8"	135 ft/lbs	175 ft/lbs	16MM	130 ft/lbs	165 ft/lbs
3/4"	185 ft/lbs	280 ft/lbs	18MM	170 ft/lbs	240 ft/lbs



INSTALLATION INSTRUCTIONS

Installation Preparation

Apply the adhesive foam to the main tubes and front and rear cross tubes. Use the roll cage as a template before cutting the foam and applying to the roll cage (**FIG 1 & FIG 2**).



FIG 1 & FIG 2 - Apply foam to roll cage

With the help of a friend, place the roof on top of the vehicle (**FIG 3**).



FIG 3 - Place the roof on top of the vehicle

INSTALLATION INSTRUCTIONS

Installation

Starting with the back side of the roof, loosley fasten the rear wings to the roof and the roof to the roll cage using the M8x20mm button head screws and M8 nylon lock nuts (**FIG 4 & FIG 5**).



FIG 4 & FIG 5 - Loosley fasten rear of roof to roll cage

Fasten the front section of the roof to the roll cage using the M8x20mm button head screws, M8 fender washers, and M8 nylon lock nuts. If light bar brackets were purchased, install them at this time as they share the front most holes that fasten the roof to the vehicle. Be careful not to overtighten the mounting hardware as it may warp the roof (**FIG 6**).



FIG 6 - Fasten the front of the roof to the roll cage

INSTALLATION INSTRUCTIONS

Installation

Light bar brackets share the mounting hardware for the 4 front most holes. (If light bar option was selected) fasten the light bar brackets to the vehicle (**FIG 7**).



FIG 7 - Fasten the light bar brackets to the vehicle

With the front roof mounting hardware tight, return to fully tighten the rear hardware. Be careful not to overtighten the hardware to prevent warping of the roof (**FIG 8**).



FIG 8 - Tighten remaining roof hardware

INSTALLATION INSTRUCTIONS

Installation

If the front light option was selected, the front light bar can now be mounted at this time (**FIG 9**).



FIG 9 - (OPTIONAL) Fasten the light bar to the vehicle

If Thumper Fab 40" light bar was selected, use the provided hardware and allen wrench in the light bar box to fasten the light bar to the light bar brackets (**FIG 10**).



FIG 10 - (OPTIONAL) installation and wiring of Thumper Fab front light bar

INSTALLATION INSTRUCTIONS


Installation

There is a hole in the roll cage (**near the A-Pillar bung**) that will allow the wiring to be routed from the A-Pillar to the light bar. This hole may need to be increased in size using a drill bit and the deutsch connector located on the wiring harness will need to be cut using a pair of snips to allow the wire to be routed inside this hole. An additional hole will need to be drilled close to the front cross tube of the roll cage to allow wire to be routed out of roll cage. Once prepped, route the wire though the roll cage (**FIG 11**).



FIG 11 - Route the light bar wire through the roll cage

Connect the wires to the switch and mount in a desired location. Open the hood of the vehicle to expose the accessory busbar. Connect the ring terminal ends of the wiring harness to the busbar, the (**Red Wire**) to the “**ACC**” terminal and (**Black Wire**) to the “**B-**” terminal (**FIG 12 & FIG 13**).



A-black
B-white
C-blue




FIG 12 & FIG 13 - Connect the Black, White, and Blue wires to the switch. Connect the ring terminals of the harness to the under hood busbar

INSTALLATION INSTRUCTIONS

PRODUCT DISCLAIMER

The installation of products sold or manufactured by Thumper Fabrication, LLC (Thumper Fab) including, but not limited to suspension components such as lift kits, audio roofs, roll cages, frame stiffener kits, and tires that exceed the original specifications for the vehicle, may change the vehicle's center of gravity and handling characteristics both on- and off-road. You are aware that the installation of tires that are larger than original vehicle specifications may reduce the effectiveness of the braking system. Use of these products may place added stress to the original factory vehicle components which could cause them to weaken or possibly fail.

Products sold or manufactured by Thumper Fab are intended for off-road use only. Operation of a vehicle modified with these products on a road could result in serious bodily injury or death, and such operation may violate the laws of your state or municipality. You agree to operate your vehicle exclusively in the manner intended by the vehicle manufacturer. You agree that failure to safely and reasonably operate your vehicle could result in serious bodily injury or death, and that, as a result of installation of this product(s) to your vehicle, extreme care must be taken to prevent vehicle rollover or loss of control, which may be more likely to occur as a result of said modifications. You will avoid unsafe maneuvers, including sudden sharp turns or other abrupt maneuvers, which could make a vehicular accident more likely. You understand that Thumper Fab is not responsible or liable for any damages or any injuries to yourself or your passengers that could occur upon possible accidents due to driver error, incorrect installations, bad judgment, incompatibility with other aftermarket accessories or natural disasters to the fullest extent allowable by law. You will have all vehicle occupants fasten seatbelts, if equipped, and wear proper safety equipment, such as DOT approved helmet and eye protection prior to operating the vehicle. You understand and acknowledge that failure to wear proper safety equipment may increase the risk of serious bodily injury or death to yourself and any passengers.

Proper installation of products sold or manufactured by Thumper Fab requires knowledge of the factory recommended procedures for removal and installation of original equipment components. Installation of these products without proper knowledge and experience may affect the performance of these components and the safety of the vehicle and cause serious bodily injury or death. It is strongly recommended that a certified mechanic familiar with the installation of similar components perform the product(s) installation.

Prior to installing any products sold or manufactured by Thumper Fab, you will perform or cause to be performed an inspection of their vehicle to confirm its condition is suitable for the installation of these products. A proper inspection of the vehicle includes confirmation that the vehicle has not been in a collision and is free of corrosion. If the vehicle is suspected to have been in a collision or misused, or is otherwise unsuitable for modification, you will not install the product(s). You will continue to inspect the vehicle prior to each use to confirm its condition is suitable for its intended use, and you acknowledge that the failure to do so may result in serious bodily injury or death, as well as damage to the vehicle itself.

You will install any warning labels provided with the product so it may be prominently seen by yourself and all passengers. You will notify all passengers of the modifications performed to your vehicle prior to operation.

Insurance companies may handle coverage of a modified vehicle differently. Please check with your insurance carrier prior to modifying the vehicle to ensure your coverage remains sufficient. Installation of this product(s) may void your vehicle warranty. If this is a concern, please check with the manufacturer or dealer before purchase or installation of this product(s).



Thumper Fab

5103 Elysian Fields Rd, Marshall, TX 75672

Customer Service: 903-472-0928

www.thumperfab.com